

ObeDog

Ergo

Weatherproof No Bark Dog Training Collar



www.obedog.us

Introduction

The **ObeDog Ergo** No Bark Training Collar eliminates your dog's bad barking habits with progressively increasing Sound and Static Stimulation controlled by its advanced built-in microprocessor distinguishing your dog's bark from other environmental noises.


Caution

- ❖ For comfort, safety and effectiveness of this product, please check the fitment of the **ObeDog Ergo** Collar frequently.
- ❖ The **ObeDog Ergo** Collar is not intended for use as a restraining collar. Do not attach a leash to the Training Collar.
- ❖ If you are using a leash, use it with a separate restraining type of collar.
- ❖ Although the Anti-bark Collar's microprocessor is designed to differentiate you dog's individual bark from other environmental noises, the unit may occasionally be activated by other vibrations or sounds..

Thank you for choosing **ObeDog Ergo** No Bark Training Collar. **ObeDog's** mission is to ensure your pet's safety by providing you the tools and techniques to successfully train your beloved pet.

Operation Guide:

The **ObeDog Ergo** No Bark Training Collar is Semi-Automatic and safe for all pets. Just install a 6 volt alkaline battery (Included), adjust the strap to your dog's neck and the **ObeDog Ergo** will automatically begin doing its job.



Sensitivity Adjustment:

There are two BUTTONS located on the top of the Receiver Unit, press the (-) to decrease or (+) to increase its sensitivity level. There are a total of 7 levels of Sensitivity and by default it is set to the 4th level automatically when you first install the battery.

Installing / Replacing the Battery:

Take off the battery cover and make sure you install the battery correctly. Install the new 6 Volt battery between the “-” and “+” contacts to ensure proper operation.

Putting Anti-bark Collar on Your Dog.

Place the unit around your dog's neck and adjust the collar length properly. The unit should fit snugly underneath your dog's neck leaving one to half a finger space. Make sure that the electrodes are in the direct contact with your dog's skin.

How does ObeDog Ergo Work?

At first bark, the **ObeDog Ergo** No Bark Training Collar will deliver a short warning tone. When a second bark is detected within thirty seconds of the first bark, a louder warning tone will be delivered. On the third bark, a more intense warning tone will sound follow by a short, mild static stimulation.

This cycle of correction will repeat through 7 correction levels. The first two levels are progressive warning tones. If your dog continues to bark, the remaining five levels will deliver a more intense tone follow by static stimulation until your dog stops for thirty seconds. For your dog's protection, should it continue to bark after the 7th level of correction, the Ergo will go into Auto-Protect mode and shut off for 1 minute then reset itself to the first level.

The **ObeDog Ergo's** correction technique will establish a pattern in which your dog will quickly learn that the stimulation was brought on by its own barking. If your dog forgets and barks again, the warning tone will remind your pet without immediately applying static stimulation. We found this technique of progressively increasing tone and static stimulation not only more humane but more EFFECTIVE in breaking their bad barking habit than most conventional shock only bark control collars.